

Installation, Operation and Maintenance Manual

Please read and save these instructions for future reference. Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Failure to comply with these instructions will result in voiding of the product warranty and may result in personal injury and/or property damage.




Table of Contents

Electrical Guidelines	1
Storage of Dampers	2
Installation	3
Maintenance	2-3
Troubleshooting	3-4

Receiving and Handling

Upon receiving dampers, check for both obvious and hidden damage. If damage is found, record all necessary information on the bill of lading and file a claim with the final carrier. Check to be sure that all parts of the shipment, including accessories, are accounted for.

Dampers must be kept dry and clean. Indoor storage and protection from dirt, dust and the weather is highly recommended. Do not store at temperatures in excess of 100°F (38°C).

Safety Warning

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment.

Electrical Guidelines

Electrical Guidelines

All wiring shall be done in accordance with the National Electrical Code ANSI/NFPA-70 latest edition, any local codes that may apply, and wiring diagrams developed in compliance with the job or project design and specifications.

Important!

Electrical input may be needed for this equipment. This work should be performed by a qualified electrician. Verify power before wiring actuator. Venco is not responsible for any damage to, or failure of the unit caused by incorrect field wiring. To avoid causing death or serious bodily harm to building occupants, follow all instructions carefully. Dampers must close completely to preserve the integrity of the fire smoke separation.

Storage of Dampers Prior to Installation

The basic intent of a proper storage of heavy duty/industrial control and bubble tight damper is to prevent physical damage, material corrosion, and deterioration of organic material.

- 1) Visually inspect the damper for damage. Store indoors, protected from sunlight, moisture, and flooding. Protect dampers from debris and dirt accumulation. Keep all conduit entry plugs and actuator access covers in place.
- 2) Dampers may be stacked and stored horizontally if wood or equivalent spacers are placed between flanges to protect finish. Do NOT store with axles vertical. Place dampers on pallets or supports to allow air circulation. Do NOT store with damper directly on concrete or ground.
- 3) The damper drive should be stored in a clean dry area. Do not stack drives on top of one another. Add desiccant to electrical compartment if storage area temperature drops below 38°F. Damage due to moisture is not covered by actuator warranty.
- 4) Consult manufacturer if storage time exceeds two years.

Installation Guidelines

Failure to follow instructions will void all warranties.

The basic intent of a proper installation is to secure the heavy duty/industrial damper into the opening in such a manner as to prevent distortion and disruption of damper operation. The following items will aid in completing the damper installation in a timely and effective manner.

- 1) Dampers are supplied standard without mounting holes. Drill or punch as required. If mounting holes are supplied, use appropriate gasketing between mating flanges. Closed cell sponge rubber, solid rubber, maximum 60 durometer, or fiberglass drop warp tape is recommended. For HBTR series, the seal between the mating ductwork and the dampers flanges should be tested to ensure a bubble tight seal is achieved. If damper is replacing existing damper, clean mating surfaces prior to installing new damper.
- 2) Allow minimum of half of the blade diameter, upstream or downstream, in the duct for blade rotation.
- 3) Damper can be mounted vertically or horizontally with axle horizontal. A split shaft collar must be added to shaft to resist the blade weight if axle centerline is other than horizontal.
- 4) Isolate damper from high vibratory loadings.
- 5) If any NEMA electrical enclosure is supplied, use appropriate electrical connections so as to maintain the NEMA rating.

Do's

- 1) Use damper lifting lugs as provided.
- 2) Install all mounting bolts before tightening. Tighten in even and staggered pattern to evenly compress flange gasketing.
- 3) Mating flange must be flat and in the same plane.
- 4) Verify that damper does not strike mating ductwork or internal ductwork reinforcing when blade is in the open position.
- 5) Provide expansion joints upstream/downstream for angled ductwork so damper is not subjected to thermal/wind load forces off the centerline of damper.

Don'ts

- 1) Do not lift damper with chain/strap with blade propped open and with chain/strap through frame as this could damage blade seal.
- 2) Do not use actuator, linkage, or axles as lifting point.
- 3) Do not use pry bar to match frame holes to mating ductwork as frame can be warped or pulled out-of-round by excessive force.
- 4) Do not tighten mounting bolts by starting at one point and "walking" around the damper as uneven flange compressing can result.

Maintenance

Greenheck's dampers are designed to be trouble free and hassle free under normal operation. The following annual damper maintenance suggestions will help to insure proper damper operation and increase the life expectancy of the damper.

Foreign Matter

Over the course of time, dirt and grime may collect on damper surfaces. The damper surfaces should be cleaned to prevent hindrance to airflow.

Moving Parts

Make sure that parts such as linkage, bearings, blades, etc. that are intended to move freely, can do so. Lubricating these components can prevent possible rusting and unnecessary friction increase. Use only a molybdenum spray oil or similar graphite based oil on sleeve bearings as regular lubricating oil will attract dirt.

Bearings. Synthetic, oil impregnated, carbon sleeve, and ball bearings (without grease fittings) do not require lubrication. Ball bearings with grease fittings should be lubricated as follows:

Maximum Duct Temperature °F (°C)	Lubricant	Minimum Frequency
250° (121°)	NLG1 Grade 2 lithium 12-hydrostearate grease	twice a year
600°(316°)	Hi temperature synthetic, Mobillith SHC100 or equal	four times a year

Closure

Remove foreign materials that may be interfering with blade closure or effective sealing of the blades with each other or with the frame.

Blade Seals. Inspect annually.

Axle seals. Inspect and adjust as necessary.

Operation

While operating the damper through its full cycle, check to see that the blades open and close properly. If there is a problem, check for loose linkage, especially at the actuator. Tighten the linkage where required.

Actuator

Cycle test actuator per manufacturer's recommendations.

Troubleshooting

The following is a cause and correction list for common concerns with the damper:

Problem	Possible Cause	Solution
Damper does not move	No power to actuator	Verify presence of correct power to actuator.
	Actuator failed	Power actuator independently of damper.
	Actuator attempting to rotate in wrong direction	Check wiring. Run actuator independent of damper if necessary.
	Linkage/coupling failed	Inspect coupling, keys, and connecting linkage for failed or broken components. Replace as required.
	No modulating signal	Verify presence of modulating signal. Verify signal is compatible with actuator. Verify if signal is driving actuator in the correct direction.
	Obstruction in damper linkage or inside duct	Inspect for projecting mounting bolts, debris inside damper and remove.
Damper attempts to move but, does not open fully	Actuator sizing incorrect (excessive torque required)	Verify that correct operating pressures, velocities, and temperatures were given to manufacturer for actuator sizing. Replace actuator if necessary.
	Obstruction in damper linkage or inside duct	Inspect for projecting mounting bolts, debris inside damper and remove.
	Modulating control not going full span	Verify control signal span from controller.
	Actuator travel stops incorrectly adjusted	Some actuators are equipped with mechanical stops to limit rotation. Adjust as necessary.
High noise level	Very high velocity/flow	Reduce flow through damper.
	No seals on dampers (HCDR)	Retrofit with blade seals.
	Damper not closing fully	Readjust actuator or drive linkage to fully close damper.
Excessive leakage across damper	Damper not closing fully	Re-adjust actuator or drive linkage to fully close damper.
	Damper not equipped with blade seals (HCDR)	Retrofit with blade seals.
	Blade edge seals failed	Replace blade edge seals.
	Stop angles not contacting blade edges	Close damper. Loosen fasteners and adjust stop angles so as to contact blade.
	Caulking failed (HCDR)	Re-caulk gaps with silicone sealant as required.
Excessive leakage through damper frame	No axle seals specified (HCDR)	Contact manufacturer for available modifications
	O-ring axle seals worn	Replace O-rings are required
	Double gland packing not tight	Tighten adjustment nuts on double gland stuffing box
	Double gland packing worn	Replace packing as required

Our Commitment

As a result of our commitment to continuous improvement, Venco reserves the right to change specifications without notice.

Product warranties can be found online at Vencoproducts.com, either on the specific product page or in the literature section of the website at Vencoproducts.com/Resources.



Phone: 1.833.881.0565 • Fax: 715.355.2399 • E-mail: info@vencoproducts.com • Website: www.vencoproducts.com